

CAT. N° 4 062 88



STOP AND GO AUTOMATIC RESETTING FOR DX³ 230 V~ - STANDARD - 2 MODULES

Pack (number of units)	1
Volume (dm ³)	1,188
Weight (g)	238,00

Product characteristics

STOP&GO automatic resetting

- For automatic resetting of 1 module per pole RCCBs and RCBOs up to 63 A
- STOP&GO is used in the event of unwanted tripping generated by temporarily electrical disturbances or other external events. Can take one control auxiliary and one signalling auxiliary. The signalling auxiliary must be placed between the STOP&GO and the control auxiliary. No tool required for assembling

Automatic resetting function

- Control voltage : 230 V~
- Number of modules : 2

General characteristics

STOP&GO connected kit and automatic resetting

Documentation



Catalogue pages & additional information

- [Description page \(p.073\)](#)
- [Dimensions of din-rail equipment](#)
- [STOP&GO automatic resetting for DX³ - Manual changeover switches for DX³](#)



Installation & technical data

- F01284EN-00



Installation instructions & related documents

- [LE04414AB](#)