
Product sheet



CLASSIA BTICINO

Roller shutter wireless switch Classia with Netatmo REF. BT-RW4027CW | EAN. 8005543651490

> <u>Visit e-catalogue</u>

Product characteristics

- Up/down/stop function
- LED indicator with low battery warning
- Supplied with a replaceable battery with an 8-year life
- White

Recommendation / Restriction

• To pair your roller shutter wireless switch, you first need to purchase and install a Classia with Netatmo connected starter pack, as well as one or more Classia with Netatmo connected roller shutter switches

The product's benefits

Installation

• Extra-slim, the roller shutter wireless switch is attached to a wall with the adhesive pads provided. It can therefore be repositioned. Can also be screwed onto a flush-mounting box

Usage

 Pair as many connected roller shutter switches as you wish and control them all with a single press on your wireless switch

Documentation

TECHNICAL DOCUMENTATION

- → LE11618AA.pdf | PDF (1.32Mo)
- IDP000362_01-EN.pdf | PDF (1.57Mo)

Agreements & Certificates

- Decl. UE RED-A 4148 A | (0.45Mo)
- E AENOR-030/002581 | (0.27Mo)